Burgess

Standard Size, Metal Case, Enclosed Terminal Micro Switches


Complementary to, and generally dimensionally interchangeable with, the plunger actuated moulded case micro switches described on the previous two pages, these metal cased models offer increased resistance to physical damage as well as a greater variety of styles. All are single-pole, changeover, snap-action switches with trident spring mechanisms exhibiting repeat accuracy of a very high order.




Cowl protected spring plunger actuator models for normal or moist environments



Spring plunger actuator with screwed sleeve for optional single-hole mounting




"Split contact" model with two top and two bottom fixed contacts and five terminals



characteristics



Spring plunger actuator with in-line roller. Single-hole mounting facilities



Adjustable roller-lever auxiliary actuator for optional use with switches having protected plungers

Construction

Switches with reference prefixed '4': single-pole, changeover, snap-action micro switches using beryllium copper trident spring with silver contacts. Normally closed only or normally open only work is obtained by using just two of the three terminals provided. Switches with references beginning '4CR' have slightly off-set plunger actuators, a feature which affects operating characteristics. All '4B' and '4C' models except 4CR7 have electrical ratings shown in table 1. Switch reference 4CR7 features wide contact separation which improves its DC performance and increases its actuating force; its electrical ratings are shown in table 2.

Switch reference 5BR: this is a 'split contact' model with five silver contacts and five terminals. In the free position the moving contact mates with two top contacts and, after changeover, it mates with the bottom two contacts. This arrangement meets the needs of some industrial applications but a discussion with Burgess Engineers is recommended before use. Frequently it is advantageous to use a double-break switch to provide the same facilities. **Fnclosure**


Metal case with plastic insulation and base plate. The cowl fitted to protected plungers is synthetic rubber.

Integral Actuators

Protected plungers: heavy duty steel type with cowl. The return to free position after operation is spring assisted.

Plungers with screwed sleeves: spring assisted, plain or with in-line plastic roller. Terminals

6BA screws and captive washers set in wiring channels and accessible when the insulated base plate is removed.



Electrical

Ratings, in amperes, are recommended maxima. The abbreviations NC and NO mean normally closed and normally open terminals.

Table 1 - Standard Ratings

Table 1 – Standard Hattings							
Voltage	Resistive	Tungsten Lamp Load		Inductive			
	Load	NC NO		Load			
AC 125 250 DC	15 15	1.5 0.7	1.0 0.5	5 5			
Up to 15	15	3	1.5	8			
30	2	3	1.5				
50	0.7	0.7	0.7	0.5			
75	0.6	0.5	0.5	0.2			
125	0.5	0.4	0.4	0.03			
250	0.25	0.2	0.2	0.02			

Voltage	Resistive	Tungsten Lamp Load		Inductive
	Load	NC	NO	Load
AC				
125	15	3	1.5	15
250	15	3	1.5	15
DC			0,004	
Up to 15	15	5	4	15
30	15	3.5	2	15
50	5	2	1.5	5
75	2.5	1	0.75	2
125	0.75	0.5	0.5	0.5
250	0.5	0.25	0.25	0.25


Table 3 Switch Poforonce ERP

Table 3 – Switch Reference 5BR								
Voltage	Resistive Load	Tungsten Lamp Load NC NO		Inductive Load				
AC 125 250 DC	10 5	1.5 0.7	1.0 0.5	5 5				
Up to 15 30 50 75 125 250	15 2 0.7 0.6 0.5 0.25	3 0.7 0.5 0.4 0.2	1.5 1.5 0.7 0.5 0.4 0.2	8 1 0.5 0.2 0.03 0.02				

Installation and Service

All models are suitable for side-mounting to a flat surface. Use M3.5 or #6 unified thread screws, preferably with lockwashers. Models with screwed sleeves may be single-hole mounted. The recommended clearance hole is 12.7 mm (0.5 in) diameter, or use a tapped hole of 11.9 mm (0.47 in) diameter, 32 TPI Whitworth form. Full installation instructions are provided with each consignment of switches.


Diagram of Connections



5BR Switch Connections

RIGHT

Split contact switches should be installed with care. If for any reason they are used as normal on-off or changeover switches they should be connected in the following manner:-



Connections made in the manner shown below should be avoided:

Environmental Data

Note one model, reference 4BR/510, page 154, is sealed and pressure tested.


Service Recommendations

WRONG

Keep switches reasonably clean, especially around the actuator area. Check periodically for secure mounting and for wear on the actuating medium.

Moulded cased models - pages 50-51 and 151-153. Double-break models - pages 55 and 157-158.

4CR



Actuator

Spring plunger with cowl protection. Compared with 4BR and 4BR/510

above, the plunger is offset by 2.0 mm (0.08 in)

Mechanism

Single-pole, changeover

Terminals Three 6BA screws with captive

washers behind removable cover

Case Metal

Electrical Rating Recommended maximum 15A

on 125 or 250 Vac.

Full ratings on page 53 (Table 1)

Free Position (max)40.8 mm1.6 inOperating Position39.31.55 in

 $\pm 0.4 \, \text{mm}$

Movement Differential (max)0.025 mm0.001 inAvailable Overtravel4.6 mm0.18 inActuating Force (max)3.9 N14 ozfRelease Force (min)1.1 N4 ozf

Mechanical Life Between 1 and 10 million

operations

Enclosure Mechanism only: IP54

Temperature −10° to +85°C Weight 96 g max

Approvals Please contact Burgess for latest

information

This model and similar models are described in detail

on pages 52-53

