

a.c./d.c. current monitoring in 1-phase mains

G2IM5AL10

Monitoring relays - GAMMA series Multifunction 16.6 to 400Hz Fault latch Supply voltage selectable via power modules 1 change-over contact Width 22.5mm Industrial design



Technical data

1. Functions

a.c./d.c. current monitoring in 1-phase mains with adjustable thresholds, timing for start-up suppression and tripping delay separately adjustable, fault latch and the following functions which are selected by means of rotary switch:

0s

0.1s

OVER	Overcurrent monitoring
UNDER	Undercurrent monitoring
WIN	Monitoring the window between Min and Max

Adjustment range

10s

10s

2. Time ranges

Start-up suppression time: Tripping delay:

3. Indicators

Green LED ON: Green LED flashes: Yellow LED ON/OFF: Red LED ON/OFF:

Red LED flashes:

indication of supply voltage indication of start-up suppression time indication of relay output indication of failure of the corresponding threshold indication of tripping delay of the corresponding threshold

4. Mechanical design

Self-extinguishing plastic housing, IP rating IP40 Mounted on DIN-Rail TS 35 according to EN 60715 Mounting position: any Shockproof terminal connection according to VBG 4 (PZ1 required), IP rating IP20 Tightening torque: max. 1Nm Terminal capacity: 1 x 0.5 to 2.5mm² with/without multicore cable end

- 1 x 4mm² without multicore cable end
- 2 x 0.5 to 1.5mm² with/without multicore cable end
- 2 x 2.5mm² flexible without multicore cable end

5. Input circuit

Supply voltage: 12 to 400V a.c.

Tolerance: Rated frequency: Rated consumption: Duration of operation: Reset time: Residual ripple for d.c. : Drop-out voltage: Overvoltage category: Rated surge voltage:

terminals A1-A2 (galvanically separated) selectable via power modules TR2 according to specification of power module according to specification of power module 2VA (1.5W) 100% 500ms

>30% of the supply voltage III (in accordance with IEC 60664-1) 4kV

6. Output circuit

1 potential free change-over contact Rated voltage: 250V a.c. 750VA (3A / 250V a.c.) Switching capacity: If the distance between the devices is less than 5mm. 1250VA (5A / 250V a.c.) Switching capacity: If the distance between the devices is more than 5mm. Fusing: Mechanical life: Electrical life Switching frequency:

Overvoltage category: Rated surge voltage:

7. Measuring circuit

Measured variable: Input: 20mA a.c./d.c. 1A a.c./d.c 5A a.c./d.c Overload capacity: a.c./d.c 20mA 1A a.c./d.c 5A a.c./d.c Input resistance: 20mA a.c./d.c 1A a.c./d.c a.c./d.c 5A Switching threshold: Max Min Overvoltage category: Rated surge voltage:

5A fast acting 20 x 10⁶ operations 2 x 10⁵ operations at 1000VA resistive load max. 60/min at 100VA resistive load max. 6/min at 1000VA resistive load (in accordance with IEC 60947-5-1) III (in accordance with IEC 60664-1) 4kV

d.c. or a.c. Sinus (16.6 to 400Hz)

terminals K-I1(+) terminals K-I2(+) terminals K-I3(+)

250mA 3A 10A 2.7Ω 47mΩ 10mΩ

10% to 100% of I_N 5% to 95% of I_N III (in accordance with IEC 60664-1) 4kV

8. Control contact Y (equipotential with measuring circuit) fault latch (Y1-Y2 bridged)

Function: Loadable Line length Y1-Y2: Control pulse length: Reset:

No max. 10m (twisted pair)

normally closed contact in the input circuit

9. Accuracy

Base accuracy: Frequency response: Adjustment accuracy: Repetition accuracy: Voltage influence: Temperature influence:

≤0.05% / °C

10. Ambient conditions Ambient temperature:

Storage temperature: Transport temperature: Relative humidity:

Pollution degree: Vibration resistance:

Shock resistance:

≤3% (of maximum scale value) -10% to +5% (16.6 to 400Hz) ≤5% (of maximum scale value) ≤2%

-25 to +55°C (in accordance with IEC 60068-1) -25 to +40°C (in accordance with UL 508) -25 to +70°C -25 to +70°C 15% to 85% (in accordance with IEC 60721-3-3 class 3K3) 3 (in accordance with IEC 60664-1) 10 to 55Hz 0.35mm (in accordance with IEC 60068-2-6)

15g 11ms (in accordance with IEC 60068-2-27)


Functions

When the supply voltage U is applied, the output relay switches into on-position (yellow LED illuminated) and the set interval of the start-up suppression (START) begins (green LED U flashes). Changes of the measured current during this period do not affect the state of the output relay. After the interval has expired the green LED is illuminated steadily. For all the functions the LEDs MIN and MAX are flashing alternating, when the minimum value for the measured current was chosen to be greater than the maximum value.

Overcurrent monitoring (OVER)

When the measured current exceeds the value adjusted at the MAXregulator, the set interval of the tripping delay (DELAY) begins (red LED MAX flashes). After the interval has expired (red LED MAX illuminated), the output relay switches into off-position (yellow LED not illuminated). The output relay again switches into on-position (yellow LED illuminated), when the measured current falls below the value adjusted at the MIN-regulator (red LED MAX not illuminated).


If the fault latch is activated (bridge Y1-Y2) and the measured current remains above the MAX-value longer than the set interval of the tripping delay, the output relay remains in the off-position even if the measured current falls below the value adjusted at the MIN-regulator. After resetting the failure (interrupting and re-applying the supply voltage), the output relay switches into on-position and a new measuring cycle begins with the set interval of the start-up suppression (START).



Undercurrent monitoring (UNDER)


When the measured current falls below the value adjusted at the MINregulator, the set interval of the tripping delay (DELAY) begins (red LED MIN flashes). After the interval has expired (red LED MIN illuminated), the output relay switches into off-position (yellow LED not illuminated). The output relay again switches into on-position (yellow LED illuminated), when the measured current exceeds the value adjusted at the MAX-regulator.

If the fault latch is activated (bridge Y1-Y2) and the measured current remains below the MIN-value longer than the set interval of the tripping delay, the output relay remains in the off-position even if the measured current exceeds the value adjusted at the MAX-regulator. After resetting the failure (interrupting and re-applying the supply voltage), the output relay switches into on-position and a new measuring cycle begins with the set interval of the start-up suppression (START).




Window function (WIN)

The output relay switches into on-position (yellow LED illuminated) when the measured current exceeds the value adjusted at the MIN-regulator. When the measured current exceeds the value adjusted at the MAXregulator, the set interval of the tripping delay (DELAY) begins (red LED MAX flashes). After the interval has expired (red LED MAX illuminated), the output relay switches into off-position (yellow LED not illuminated). The output relay again switches into on-position (yellow LED not illuminated) when the measured current falls below the value adjusted at the MAXregulator (red LED MAX not illuminated). When the measured current falls below the value adjusted at the MIN-regulator, the set interval of the tripping delay (DELAY) begins again (red LED MIN flashes). After the interval has expired (red LED MIN illuminated), the output relay switches into off-position (yellow LED not illuminated).




If the fault latch is activated (bridge Y1-Y2) and the measured current remains below the MIN-value longer than the set interval of the tripping delay, the output relay remains in the off-position even if the measured current exceeds the value adjusted at the MIN-regulator. If the measured current remains above the MAX-value longer than the set interval of the tripping delay, the output relay remains in the off-position even if the measured current falls below the value adjusted at the MAX-regulator. After resetting the failure (interrupting and re-applying the supply voltage), the output relay switches into on-position and a new measuring cycle begins with the set interval of the start-up suppression (START).




G2IM5AL10

Connections


Range 20mA with power modul 24V a.c. and fault latch




Range 1A with power modul 230V a.c. and fault latch



Range 5A with power modul 400V a.c. without fault latch



Dimensions



RELEASE 2011/10

Subject to alterations and errors

